


Pipe Joint Subassembly Spec and Notices for Installation

1. Notices for Installation:

During the installation of the unit, the installation space of the pipe joint assembly should be taken into account. See the figure below for its installation dimension. (mm)



2. Pipe Joint Subassembly Spec:

Serial No.	Pipe Joint Subassembly Spec (①→②)	Size L1(mm)	Size L2(mm)	Quantity
1	6.35→9.52	79	88	2
2	12.7→9.52	113	118	2
3	12.7→15.9	113	123	2
4	9.52→6.35	111	141	1
5	15.9→9.52	176	165	1
6	9.52→12.7	111	95	1
7	15.9→12.7	176	133	1

